



ETC TT Torque Tool & TW T-Wrenches for Connectors



ETC TT Torque Tool



ETC TWST Step-tip T-Wrench




ETC TW T-Wrench

General:

The T-Wrench comes in two versions: T-Wrench & Step-tip T-Wrench. They are used to install the Loadbreak Bushing Insert, the Loadbreak Reducing Tap Plug, the Bushing Surge Arrester, the T-II Connector, the Tee Connecting Plug or related connectors.

The Torque Tool is required to check the torque of a 15kV T-II Connector or Bushing Adapter when it is installed on a 600A bushing interface. It is precision calibrated and shotgun stick operable.

DIMENSIONS(mm)



ETC Torque Tool




E.T.C AUSTRALIA


Tel:+61 08 9437 1313 Fax:+61 08 9437 1103



800-03



ETC Step-tip T-Wrench



ETC T-Wrench

Ordering Information:

To order a T-Wrench or Torque Tool, please refer to the following Catalogue Numbers and specify the quantity.

Catalogue Number
ETC TT Torque Tool
ETC TW T-Wrench
ETC TWST Step Tip T-Wrench